

# OTTERBOX

## Bluetooth Audio Adaptor User Guide



### General /

- Bluetooth Range: 10 meters
- Talk time: 7 hours\*
- Play time: 6.5 hours\*
- Standby time: 300 hours
- Durable metal clip attaches to clothing and straps

### Use /

#### CHARGE

- Fully charge adaptor for first use — 1 hour

#### POWER ON

- Toggle switch to 'on' position
- Blue LED flashes 3 times

#### PAIR

- Turn Adaptor on, pairing mode starts automatically
- Follow device manufacturer pairing instructions

#### PLAY/PAUSE

Press multi-function button

#### POWER OFF

Toggle switch to off position

#### CALLS

- Answer – press multi-function button
- End call – press multi-function button
- Reject call – Press multi-function button for 2 seconds

### Care & Maintenance /

#### CLEANING

1. Wipe with a dry cloth
2. Do not use solvents, chemicals, cleaning solutions, alcohol, ammonia or abrasives

### Customer Service /

1-855-688-7269  
USA + Canada - Toll Free  
support@otterbox.com  
otterbox.com/support

\*at 80% volume

**REGISTRATION**

Register your new OtterBox Earphones right away: [otterbox.com/en-us/account-register](https://otterbox.com/en-us/account-register)

What you get:

- Important product alerts, updates and tips
- Streamlined service and support
- First dibs on special offers, promos and contests
- No bug policy — tell us how often you want to hear from us

**SUPPORT**

[otterbox.com/support](https://otterbox.com/support)

If the OtterBox product was purchased from a retailer or other reseller of OtterBox product, you should first contact that retailer/reseller to ask about their return policy.

If you are within the return policy of your retailer/reseller, you should return your OtterBox product to them.

If you are no longer covered by the return/refund policy of that retailer/reseller, please contact OtterBox support.